

14300 Saxophone stand

Product variant

14300-000-55 - black

Data

EAN	4016842103744
Gewicht	1.04 kg
Height	485 mm
Instrument support	non-marring material
Leg construction	socket with foldable legs
Material	steel
Special features	fiberglass reinforced plastic base; flexible upper support arm; lower support arm bracket with several vertical locking positions
Suitable for	Eb Alto and Bb Tenor Sax
Type	black



Adjustable folding stand for Eb Alto and Bb Tenor Sax. Fiberglass reinforced plastic base. Flexible upper support arm for different bell sizes. Lower support arm bracket with several vertical locking positions. All instrument support parts covered with exclusive non-marring plastic coating. To be used with peg holder 14301 and clarinet peg or with peg holder, adapter 15281 and pegs for trumpet, soprano sax or flugelhorn.