


Spare parts list

# 11515 Music holder for dulcimer stand 28070

11515-000-55 - black

\*Rev01



Position	Description	Article No.	Quantity
1	Clamping screw M6 x 12 mm	01-83-040-55	1
2	Washer	03-11-405-25	1
3	Screw connection of the music desk	3-00-000-005	1
4	Music desk complete	6-10065-1-55	1