

14300

## Saxophone stand

### Product variant

US-14300-000-55 - black

### Data

<b>EAN</b>	4016842103744
<b>Height</b>	19.094"
<b>Instrument support</b>	non-marring plastic material
<b>Leg construction</b>	socket with foldable legs
<b>Material</b>	steel
<b>Special features</b>	fiberglass reinforced plastic base; flexible upper support arm; lower support arm bracket with several vertical locking positions
<b>Suitable for</b>	Eb Alto and Bb Tenor Sax
<b>Type</b>	black
<b>Weight</b>	2.291 lbs



Adjustable folding stand for Eb Alto and Bb Tenor Sax. Fiberglass reinforced plastic base. Flexible upper support arm for different bell sizes. Lower support arm bracket with several vertical locking positions. All instrument support parts covered with exclusive non-marring plastic coating. To be used with peg holder 14301 and clarinet peg or with peg holder, adapter 15281 and pegs for trumpet, soprano sax or flugelhorn.